

### 3 - 60Hz C3-A WJ200 Frequency Drive Settings

Parameter	Value
B037	00
F002	2.0
F003	6.0
A001	01
A002	01
A003	60
A004	122
A011	30.5
A012	122
A042	20
A043	50
A044	00
B021	00
B012	SET TO MAXIMUM

This vaule must be changed FIRST, otherwise you will not able to get to all the other parameters